

# AR Link System Repeaters

## *Linked full time:*

443.200	+5.00	114.8	N5CG	CAUHF Main Hub	(Shinall Mt)
443.200	+5.00	82.5	N5CG	Alexander remote receiver	(Courtesy of N5YLE)
443.500	+5.00	136.5	W5BXJ	Downtown Malvern	(Courtesy of W5BXJ)
443.600	+5.00	114.8	N5CG	Lono/Malvern	(K5RQO QTH)
444.700	+5.00	114.8	N5CG	Downtown Little Rock/NLR	(Fort Roots VA Med Ctr)
145.330	-.600	114.8	N5CG	Downtown Morrilton	(Caruthers Hill)
145.490	-.600	114.8	N5CG	CAUHF Main VHF	(Shinall Mt)
146.640	-.600	131.8	N5CG	Benton	(Adrian St water tower)
146.790	-.600	114.8	N5CG	Gillette	(Near Dewitt and Dumas)
147.030	+.600	110.9	W5AUU	Conway	(Courtesy of N5GC)
147.255	+.600	114.8	N1RQ	Sherwood	(Courtesy of N5QLC)

## *Non linked repeaters:*

444.850	+5.00	114.8	N5CG	Ark. School for the Blind	(Courtesy of K5XT)
443.000	+5.00	100	N5CG	Shinall Mountain	(Courtesy of KD5OCQ)
146.775	-.600	162.2	N5CG	Shinall Mountain	(Courtesy of AE5RW)

All AR Link repeaters except the non linked ones have access to Echolink and IRLP. The node numbers are as follows:  
Echolink # 503215  
IRLP # 3807

To access IRLP, dial **B** and the desired node number. To access Echolink, dial **A** and the desired node number. Dial **73** to disconnect. **Always give your call sign before entering tones.**

**\*\*\*Please note\*\*\***

***When a user presses his or her PTT on the AR link system, there will be a time delay of 1 to 2 seconds for all of the repeaters to link up. Because of this, it is important to press the PTT and pause for 2 seconds before speaking. If one fails to do this, the first 2 seconds of audio will be omitted causing confusion for everyone.***

**While using this system please remember you will be heard on no less than 10 repeaters. Please use the golden rule when it comes to long rag chews. A lot of people are listening. The 443.000 should be used for extended QSOs.**

\*\*\*\*\*